

## 3 Valve CAI Fitting Instructions

**Thank you for choosing Blue Power Cold Air intake.**

You are fitting the a record breaking CAI to your car that has been proven on the Drag Strip with records in Fastest 3 Valve, N/A 6, Boss 260/290/302/315 and Blown 260/290 and these records still stand....



Remove existing air box from car.

3 x 10mm head bolts

Breather hose at rear



3 x 8mm head bolts.

**Bluepower Racing Developments**

Street - Strip - Circuit - Marine Engines

Address: 47 Cooper Street, Campellfield VIC 3061 Australia Phone +61 03 9305 3000

Fax: +61 03 9303 9247 Mob: +61 0438 351 351 Email: [sales@bluepower.com.au](mailto:sales@bluepower.com.au) Web: [www.bluepower.com.au](http://www.bluepower.com.au)

[WWW.BLUEPOWER.COM.AU](http://WWW.BLUEPOWER.COM.AU)



Bend Air Cond pipe  
away from edge.



The pipe needs to be  
about here to fit the new  
air box.

**Bluepower Racing Developments**

Street - Strip - Circuit - Marine Engines

Address: 47 Cooper Street, Campellfield VIC 3061 Australia Phone +61 03 9305 3000

Fax: +61 03 9303 9247 Mob: +61 0438 351 351 Email: [sales@bluepower.com.au](mailto:sales@bluepower.com.au) Web: [www.bluepower.com.au](http://www.bluepower.com.au)



Remove the wiring plug that's next to the washer bottle and just let it hang down out of the way.

*Not applicable to all models*



Sit the air box panel in place using the lid to get a nice snug fit then mark with a texta, remove lid and drill holes to put panel in place. Use screws supplied, there's a bracket up the front near the headlight, I don't attach this it's your choice.



Place rubber onto throttlebody with clamp but leave loose until all pipe work is in place.

Connect rear breather Hose and tighten clamp.

On some cars this rubber may just touch the bonnet, you can squash the pipe in a vice a little if you wish.



Sit air filter in place and attach to pipe work, all clamps can now be tightened.

**Bluepower Racing Developments**

Street - Strip - Circuit - Marine Engines

Address: 47 Cooper Street, Campellfield VIC 3061 Australia Phone +61 03 9305 3000

Fax: +61 03 9303 9247 Mob: +61 0438 351 351 Email: [sales@bluepower.com.au](mailto:sales@bluepower.com.au) Web: [www.bluepower.com.au](http://www.bluepower.com.au)

THE FINAL FINISH SHOULD LOOK LIKE THIS  
“Enjoy your new found power”



It is the responsibility of the fitter to see to it that all harnesses/lines both ac and steering and any other relevant hardware is moved into a safe and secure area that will not interfere with the safe workings of the motor vehicle.

It is also the responsibility of the fitter to ensure that during the fitting process the appropriate precautions are taken to prevent injury.

Make sure battery is disconnected, wear protective safety gear where applicable.

*Bluepower Racing Developments.*

**Bluepower Racing Developments**

Street - Strip - Circuit - Marine Engines

Address: 47 Cooper Street, Campellfield VIC 3061 Australia Phone +61 03 9305 3000

Fax: +61 03 9303 9247 Mob: +61 0438 351 351 Email: [sales@bluepower.com.au](mailto:sales@bluepower.com.au) Web: [www.bluepower.com.au](http://www.bluepower.com.au)

[WWW.BLUEPOWER.COM.AU](http://WWW.BLUEPOWER.COM.AU)